

ENJOY THE RIDE...



... RIDE TO ENJOY

**MAKE:** TOYOTA

**TYPE:** 4 Runner / Surf

**MODEL:** KZN185 3.0L TD

**YEAR:** 1995 on

RZN185 2.7L Petrol, VZN 185 3.4L V6

**DETAIL:** Station Wagon

TOY-83

FRONT		TYPE	QTY	PART NUMBER
<p><b>COIL SPRING</b> Type 'C'</p>				
<p>RZN185/VZN185</p>				
<p>Linear Rate Standard Height</p>		1		<b>C59-132</b> (Pair)
<p>Linear Rate Raised Height (Recommended) 20mm Lift</p>		1		<b>C59-274</b> (Pair)
<p>Linear Rate Raised Height 45mm Lift</p>		1		<b>C59-276</b> (Pair)
<p><b>KZN185 Turbo Diesel</b></p>				
<p>Linear Rate Standard Height</p>		1		<b>C59-274</b> (Pair)
<p>Linear Rate Raised Height (Recommended) 30mm Lift</p>		1		<b>C59-276</b> (Pair)
<p>Linear Rate Raised Height 50mm Lift</p>		1		<b>C59-134</b> (Pair)
<p><b>SHOCK ABSORBER</b></p>				
<p>Type 'G' 'H' 'K'</p>				
<p>Heavy Duty Gas Complete with Spring Seat</p>		K	2	<b>GS59-222</b>

REAR		TYPE	QTY	PART NUMBER
<p><b>COIL SPRING</b> Type 'C'</p>				
<p>Variable Rate Standard Height</p>		1		<b>C59-129V</b> (Pair)
<p>Linear Rate Standard Height 40mm Lift</p>		1		<b>C59-133</b> (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>		1		<b>C59-131</b> (Pair)
<p>Linear Rate Raised Height Heavy Duty 100Kg Accessories</p>		1		<b>C59-137V</b>
<p><b>SHOCK ABSORBER</b></p>				
<p>Type 'A' 'B' 'C'</p>				
<p>Heavy Duty Gas</p>		B	2	<b>GS59-223</b>