

ENJOY THE RIDE...



... RIDE TO ENJOY

**MAKE:** MAZDA

**TYPE:** Bravo

**MODEL:** B2200, B2500, B2600

**YEAR:** 03/1987 on

**DETAIL:** Pickup, Ford Raider / Courier, Proceed

MAZ-51



FRONT		TYPE	QTY	PART NUMBER
<p><b>TORSION BAR</b></p> <p>Type 'D'</p> <p>Heavy Duty Rate Increased Length 926mm</p>		D	2	<b>TB39-1546</b> (Pair)
<p><b>SHOCK ABSORBER</b></p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		B	2	<b>GS19-082P</b>

REAR		TYPE	QTY	PART NUMBER
<p><b>LEAF SPRING</b></p> <p>Type 'B'</p> <p>5 + 2 Leaves Raised Height (35mm Lift) Medium Load to GVM</p> <p>6 + 2 Leaves Raised Height (35mm Lift) Heavy Duty Up to 200Kg to GVM</p>		B	2	<b>MAZ-003-R</b>
<p><b>SHACKLE BUSHES</b></p> <p>Rubber Polyurethane Metal</p> <p>'A' Type 'B' 'C'</p> <p>Kit Contains: 2 x SPF311 4 x SPF502 4 x SPF753</p>		B	1	<b>PB39-1058K</b>
<p><b>U-BOLT KIT</b></p> <p>Type 'A' 'B' 'C'</p> <p>Kit Contains: 2 x UB59-453-3</p>		A	2	<b>UB59-453-3K</b>
<p><b>SHOCK ABSORBER</b></p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		A	2	<b>GS19-081T</b>
<p><b>SHACKLE KIT</b></p> <p>'A' 'B' Type 'C' 'D'</p> <p>Greasable: Fit in Pairs</p>		C	2	<b>SK59-010</b>